



INSTALLATION INSTRUCTIONS

POWER SUPPLY KIT M119046

FOR MODELS: AC2030TNA / TG2030TN.

NOTE: BE SURE TO FOLLOW NATIONAL ELECTRICAL CODE, ANSI/NFPA 70, OR CANADIAN ELECTRICAL CODE, PART I, CSA C22.1 AND ALL LOCAL CODES FOR ELECTRICAL WIRING WHEN FOLLOWING THESE INSTRUCTIONS. KEEP POWER WIRES AWAY FROM ANY HOT SURFACES ON THE FURNACE. ANY CUTS, DRILLS OR NOTCHES MADE TO ANY STUDS OR JOISTS MUST BE APPROVED PER LOCAL CODES.

INSTALLING THE POWER SUPPLY KIT:

1. LOCATE AND TEMPORARILY FREE THE CONTROL MODULE BY UNSCREWING IT FROM THE HEAT SHIELD.
2. FIND THE POWER SOCKET ON THE CONTROL MODULE.
NOTE: DO NOT ALLOW ANY WIRING TO CONTACT THE GAS LINE. SEE LOCAL CODES FOR GAS LINES AND ELECTRICAL WIRING FOR MORE INFO.
3. PLACE THE POWER CABLE THROUGH THE HOLE ON THE BOTTOM OF THE BRACKET AND CLIP THE NEW STRAIN RELIEF ONTO IT.
4. PLUG THE POWER CABLE INTO THE CONTROL MODULE, THEN SECURE THE STRAIN RELIEF TO THE BRACKET.
5. REINSTALL THE CONTROL MODULE AND MAKE SURE ALL WIRES ARE PROPERLY SECURED AND IN PLACE.
6. PLUG POWER CABLE INTO THE NEAREST OUTLET.
7. TURN ON CONTROL MODULE WHEN READY TO FIRE UP.

REPLACEMENT PARTS TABLE			
REFERENCE #	ITEM NUMBER	DESCRIPTION	QUANTITY
1	P323856	AC POWER ADAPTER	1
2	P012900	1/2" STRAIN RELIEF	1



NOTE: Refer to your owner's manual for additional information and to be sure this accessory is of the type and design required for use with your furnace.